



**CONTEC**

CONTAMINATION CONTROL TECHNOLOGY

P.O. BOX 530 • SPARTANBURG, SOUTH CAROLINA 29304 • (864) 663-8434 • 1-800-289-1112 • FAX (864) 663-8444

8014-39 JUN-1 17 53

May 28, 1999

Dockets Management Branch (HFA-305)  
Food and Drug Administration  
5630 Fishers Lane, Room 1061  
Rockville, MD 20852

Dear Sir or Madam:

Please find attached a copy of our testing and research in the area of sanitization methods for food processing facilities.

In particular, our work offers interesting data regarding the sanitization of gloved and ungloved hands. We believe the data will contribute to future regulatory decisions concerning the use of gloved versus ungloved hands in the preparation of food products.

Accordingly, we request that the attached be considered for inclusion in the white paper on this subject to be prepared by FDA. If you have any questions regarding the enclosed, please contact me at 800-289-5762 Extension 237.

Sincerely,

Kenneth J. O'Connor  
Cleanroom Business Manager

99N-0438

C4

# IMPROVED SANITIZATION METHODS FOR FOOD PROCESSING FACILITIES ---

By Mel Barutha, Jackson Burnett, Suzanne Hofford, Ken O'Connor, and Myron Shuler

8015 '99 JUN -1 A7:53

## INTRODUCTION

What is contamination? The answer to this question is completely dependent upon the situation and the ultimate mission to be attained.

In industrial manufacturing environments, contamination issues vary by industry segment. For microchip makers, particles are the most significant form of contamination. If you have a particle of greater than 0.2 microns, and it gets on a chip when it's being made, you have a chip, which will not function and is off quality. For pharmaceutical manufacturers, on the other hand, bacteria and pyrogens are a greater concern than particles because they contaminate the injectable drug and also create off-quality or unusable products. When painting a car, lint or use of the wrong cleaning agent can cause a bad paint job resulting in rework. Consequently, each process has some form of contamination to which exposure makes a product that is unacceptable for sale or consumption. Efforts to eliminate sources of the contamination always result in improved quality and throughput. In many instances, the improved quality also results in improved safety for consumers.

In the food industry, high microbial level contamination can be detrimental to final product quality. Recent product recalls due to unacceptable levels of *Listeria*, *E. Coli*, and *Salmonella* have heightened our awareness to this costly and potentially fatal reality.

The most common sources of contamination in food are human hands, work surfaces, processing equipment, residuals from chemicals and disinfectants, and cross contamination from other products in the plant.

No longer participants in a low technology industry, increased customer demands for safer, more convenient products manufactured to more stringent quality standards are the expected norm for food processing companies. For example, the new Hazard Analysis and Critical Control Points program has been implemented by the government as a system of contamination control for meat and poultry plants. As pathogens and biological contaminants become resistant to disinfectants, our ability to deal with them must become more focused and more flexible. Industries that once produced in uncontrolled environments are now legally finding themselves responsible for activities not addressed previously. Uncontrolled environments in the food industry are increasingly moving from controlled environments to cleanrooms and, ultimately aseptic areas. Products and protocols for process control are becoming more complex. Training of an ever-changing employee base makes effective implementation more problematic. In the future, these high tech solutions for high-tech areas will need to become more simplistic.

For years, product quality was assured through vigorous sanitization methods. Many sanitizing agents and methods were employed. Some included general spraying of equipment by night cleaning crews and wipe down of surfaces between shifts coupled with general housekeeping methods throughout the processing facility.

The truth, and we all know it, is that the BEST sanitization procedures are those that are simple and have the least chance of variation. In general, cleaning is performed by hand. As a result, human error sometimes plays a significant role in the failure of existing sanitization methods. Successful completion of assigned duties and responsibilities by cleaning and sanitizing personnel is critical to outgoing product quality levels.

For the most part current cleaning methods are complex. The associates performing this work must first clean and sanitize themselves prior to donning required garments and safety equipment. This is a very critical activity as we have already learned from the cleanroom processing industries since the most likely source of product contamination is exposure to individuals working in process areas.

Because sanitizing chemicals are provided in bulk packaging and, in many instances, in concentrated form, personnel performing cleaning operations are expected to measure out prescribed amounts of the sanitizing material for their daily use. In addition to measuring materials, the associates are required to dilute chemicals to the proper use dilution and mix the resultant solution to insure proper level of activity. As you might expect, the possibility for errors increases especially when production levels ramp up and product changeovers are more frequent.

Additional challenges to be addressed include proper application of sanitizing solutions to irregular surfaces or to complex assemblies with several layers of internal surfaces that must be thoroughly sanitized. The application method is many times left to the discretion of the cleaning associates. Generally assumed to be a simple choice, the decision to spray or wipe on sanitizers is not always specified by the chemical manufacturer. As a result, the food processing company --- specifically the cleaning personnel --- makes the call. Little assistance is provided by the chemical supplier in determining the proper amount of solution to be applied to surfaces to be sanitized. As a result, the interpretation of the proper sanitization will vary from employee to employee. The process will not be reproducible and the level of microbial reduction unpredictable.

Efficacy data to validate the sanitizing process is often not available requiring that the data be developed by food processors. If time is not taken to develop validated methods, the resultant sanitizing process will be unreliable and a wasteful endeavor.

Effective sanitizing processes are based on the assumption that the surface has been thoroughly cleaned and decontaminated of food residues, meat residues and waxy coatings of fat. It is important that protocols address methods for proper cleaning of equipment, utensils and other food contacting surfaces. Since many raw foods are not completely soluble in aqueous solutions, cleaning must be performed with systems that will solubilize fats and proteins, but be free rinsing prior to application of the sanitizing

solutions. The cleaning systems must be approved for food applications and not limit the efficacy of the sanitizer.

To reduce the possibility for error, we must employ cleaning and sanitizing methods that are simple and convenient, requiring minimal effort. As the food industry moves to adopt increased quality standards, the ideal methods will be readily integrated into good manufacturing practices systems of reproducibility, efficacy validation and lot to lot traceability.

We all understand the cost of errors resulting from failed sanitizing methods. Product recalls result in lost business, negative publicity, increased scrutiny by regulatory agencies and serious illness or death.

Drawing once again from the model in other industries, the implementation of improved, simplified methods afford certain competitive advantages. Through simplification of processes, the time required for cleaning and sanitization is reduced resulting in decreased labor costs. Improved sanitation methods will contribute to reduced product microbial levels with potential increases in product shelf life, taste and appearance, and a reduction in waste.

As increased demands are placed on manufacturers to minimize the exposure of consumers to toxic levels of microbial contamination, it will be necessary to re-define current methods of food manufacturing. More companies will implement good manufacturing methods and in some instances consider aseptic processing. In fact some meat products will soon be exposed to low levels of gamma radiation in an attempt to further decrease and control pathogens in raw meat products. In this paper we will discuss two new sanitizing systems which can be readily adopted in all food processing applications. The improved methods can be implemented with few changes to existing systems at minimal cost, but with dramatic reductions in foodborne pathogens and increased control of product quality.


## QUAT WIPER

The first system is for the sanitization of food contacting surfaces, other than worker hands. In this system, a nonwoven wiper fabric is coated with a metered amount of a solution of quaternary ammonium compounds ( quat ). Following the coating process, the wiper substrate is dried, cut to size and packaged. The quaternary compounds incorporated into the wiper substrate are widely recognized as safe and efficacious for sanitizing food-contacting surfaces when used in concentrations less than 200 ppm. In this system the concentration ranges from 140 to 180 ppm. A dual quat system was selected because it is more effective than either quat when used alone. There is a synergistic effect when used in combination, because a more optimum balance between hydrophilicity and lipophilicity is established with a dual system. As a result a dual quat system is more effective at traversing cell wall barriers, allowing for greater germicidal efficacy.

The wider variety of alkyl groups provides a greater diversity of microbial activity with yeast and fungi more sensitive to C12, gram-positive bacteria to C14 and gram-negative bacteria more sensitive to C16 quaternary ammonium compounds.

The dual quat system in this improved method of sanitization consists of a 50/50 mixture of N-Alkyl (60% C14, 30% C16, 5% C12, 5% C18) dimethyl benzyl ammonium chlorides and N-Alkyl (68% C12, 32% C14) dimethyl ethyl benzyl ammonium chlorides as the active ingredients of the surface sanitizing wiper. Chemical structures for the dual quat system are provided in Table 1. Inert ingredients include propylene glycol as the diluent along with a wetting agent and a Turquoise pigment. The diluent is required to insure uniform coating on the wiper and, ultimately, reliable release from the nonwoven substrate during use. The wetting agent works in concert with the propylene glycol, insuring that the sanitizing solution uniformly coats the irregularities of the surfaces to be sanitized. The additional wetting agent augments the surfactant effects of the higher molecular weight quats to insure the thorough wetting of hydrophobic surfaces made from polypropylene, polyethylene and polyester plastics.

TABLE 1



Where  $\text{R}_1 = 60\% \text{ C14}, 30\% \text{ C16}, 5\% \text{ C12}, 5\% \text{ C18}$   
and  $\text{R}_2 = 68\% \text{ C12}, 32\% \text{ C14}$

A couple of very valid questions would be how are the concentrations of the solutions applied to each towel verified, and how can you be sure that you are getting the necessary amount of chemical on the towels to perform the task. As with any process, quality control is of the utmost importance. The method of verifying the concentration of the initial solution applied to each towel and of the active solution on the towel is titration. This method is an accurate way to determine the concentrations of the active ingredients present in the solutions before application on the towels and once applied to the towels. Titration is performed by reaction with sodium tetraphenylboron in the presence of methyl orange as the indicator (Reference LaMOTTE Test # 3043). In the titration, the methyl orange changes from a green color to milky, amber red at the equivalence point.

The food surface contact towel is activated by placing the towel in one gallon of water - hot or cold. Due to the presence of the Turquoise pigment, the solution becomes a green color, indicating that the water is an active quaternary ammonium compound solution that contains less than 200 ppm active quat. This solution may be used for up to eight (8) hours on surfaces that have been thoroughly cleaned prior to sanitization. It is important

to note that the quat wiper should be used to sanitize only surfaces that have been thoroughly cleaned. Introduction of organic debris from meat cutting or other gross food particles will limit the effectiveness of the quat system and greatly reduce usable life of the activated solution.

During the manufacture of the quat wiper, the polyester / cellulose fabric is immersed in a quaternary ammonium solution bath that contains  $250 \pm 50$  ppm quaternary compound. By controlling the add-on weight of the solution, the resultant surface sanitizing towel will contain  $160 \pm 20$  ppm quaternary compound.

Testing of the effectiveness of the quat wiper on food contacting surfaces indicated that the concentration of the activated solution is effective in reducing microbial levels on food contacting surfaces. Table 2 summarizes the testing conducted to date on actual processing surfaces used in the production of spices and ready to eat food products. Results are reported as aerobic plate counts ( CFU --- colony forming units ) taken using sterile swabs from a 2 inch by 2 inch square area of each test surface. The sanitization process was accomplished by using the wiper to thoroughly wet the surface with the activated solution, which was allowed to remain in place for at least one minute. Following exposure, excess solution was wiped up and the surface was allowed to dry prior to swabbing with sterile swabs.

TABLE 2 --- Processing Surfaces

LOCATION	PRE-SANITIZATION	POST-SANITIZATION
Table	430	130
Knife	60	190
Bin # 1	70	20
Bin # 2	7800	30
Transfer Bin Lid # 1	< 10	< 10
Shovel	7800	130
Bin Lid # 2	530	10
Plastic Bin	20	190
Plastic Rake	21,000	3600
Garbage Can	5,400	180
Break Room	320	1200

None of the samples contained *Staphylococcus aureus*, *Salmonella* or *Escherichia coli* CFU's. With the exception of two results, significant reduction in plate counts were observed. The quat wiper exhibited the greatest effect on surfaces with the highest microbial load prior to sanitization. The increase observed on the Break Room surface was attributed to experimental error, whereby the 2 inch by 2 inch sampling template was exposed to an unsanitized area.

Similar favorable results were observed on the surfaces of gloved and ungloved hands as depicted in Tables 3 and 4.

TABLE 3 --- Gloved Hands

LOCATION	PRE-SANITIZATION	POST-SANITIZATION
Glove # 1	6,600	130
Glove # 2	410	<10
Glove # 3	50	10
Glove # 4	30	<10

TABLE 4 --- Ungloved Hands

LOCATION	PRE-SANITIZATION	POST-SANITIZATION
Female	< 10	< 10
Male # 1	10	<10
Male # 2	150	660
Male # 3	90	20

As indicated previously, ungloved hands are a potential source of contamination in most food processing environments. However, the hands of the subjects in this test even when ungloved were found to be relatively low in microbial contamination.

Similar favorable sanitizing results were observed on surfaces found in the packaging area and spice processing equipment. Tables 5 and 6 summarize the results of this testing. Once again, the results are more dramatic on sanitizing surfaces with the higher levels of microbial contamination.

TABLE 5 --- Packaging Line

LOCATION	PRE-SANITIZATION	POST-SANITIZATION
Upper Weigh Cell	2,500	50
Dispensing Cone	3,400	<10
Lower Weigh Cell	1,600	20
Transfer Bin	1,000	20
Transfer Bin Cover	6,600	10
Table	9,600	1,300
Shovel	1,200	<10
Prod	43,000	20
Plastic Bucket	5,400	30
Shaft-Lower Bucket	1,100	3,500

TABLE 6 --- Spice Processing &amp; Packaging

LOCATION	PRE-SANITIZATION	POST-SANITIZATION
Spice Bin - Left	66,000	60
Spice Bin - Right	510	240
Spice Scoop	72,000	130
5 gallon Bucket	36,000	80
S/S feed hopper	1,100	20

TABLE 6 --- Spice Processing &amp; Packaging (cont'd)

Plastic Bucket	500	30
Plastic Feed Port	710,000	210
S/S scoop	280	100
5 gallon Bucket	12,000	200
Bin S/S	50	90
Plastic Prod	3,000	30
Exit-mixing bin	2,500	310
S/S shovel	5,200	530
Scoop, plastic	2,700	40

Quaternary ammonium compounds are potent, broad-spectrum disinfectants. When used as active ingredients in formulations such as hard surface disinfectants, sanitizers and/or certain types of water treatment formulations, quaternary ammonium compounds have been found to provide superior biocidal action against a broad spectrum of microbial organisms such as: bacteria, fungi, viruses and algae. Quaternary ammonium compounds especially the dual quat systems deliver potent germicidal action even in heavy organic soil loads. Based on the test data, one can conclude that the quat wiper method of delivering quaternary ammonium based disinfectants is a safe, simple and effective approach for sanitizing food processing surfaces and equipment. Since the testing was conducted on surfaces sanitized with a single application of the quat wiper system, it can be expected that multiple applications of the quaternary ammonium sanitizer will provide further reductions in surface microbial levels.

## IODINE WIPER

The iodine wiper represents a new technology for the application of antimicrobial materials to the hands of food processing / food handling personnel. Essentially, the wiper is a handwash towel that is comprised of a 5% Povidone-Iodine solution (PVP) coated onto a 100% polypropylene nonwoven wiper substrate. The PVP wiper is designed to provide a uniform amount of sanitizer to the surface of the hand. In its present embodiment, the treated wiper can be used to reduce microbial levels on worker hands via a 15 second wipe on hands that are dry or pre-wetted.

The PVP solution is mechanically applied using processes similar to those employed in the preparation of the quat wiper. The 5 % povidone-iodine solution is lightly applied onto the surface of the towel substrate. The 5 % PVP solution contains 0.5% active iodine. By controlling add-on weights, the resultant Iodine Wiper contains  $750 \pm 250$  ppm ( $0.075 \pm 0.025$  %) iodine.

Titration for active iodine involves reaction with lactic acid and potassium iodide in the presence of sodium thiosulfate. Addition of lactic acid and potassium iodide to the iodine solution under test imparts a blue coloration to the solution. The solution changes from blue to a clear liquid at the equivalence point upon the addition of a standard sodium thiosulfate solution ( Reference LaMOTTE Test # 7253).




For many years, PVP iodine solutions have been recognized as effective antimicrobial agents for use on human skin. Specifically, a FDA Monograph issued in 1994 allows the use of 5 to 10% PVP Iodine solutions as an antiseptic handwash for healthcare personnel.

PVP Iodine has broad-spectrum activity - against bacteria, fungi, viruses, protozoa cysts and spores. It has been used as a general antiseptic in the treatment of skin infections, cuts, etc. It is the main component in the popular Betadine® solution. PVP Iodine is also the antimicrobial agent used in physicians' scrub kits.

The antimicrobial properties of PVP iodine coupled with a low toxicity to humans suggests that the use of this compound as part of a quality control regimen in food processing facilities will contribute to the reduction of in-plant microbial levels. In particular use as an antiseptic hand wipe will afford better protection against contamination from the hands of food processing personnel.

PVP Iodine is a complex molecule in which iodine is bound to the carrier molecule, povidone. The complex, PVP Iodine, slowly releases inorganic iodine when in contact with the skin. Only a small amount of iodine is released at any one time, giving PVP Iodine a lower irritant potential and longer duration of microbicidal action than conventional iodine solutions. The chemical structure of PVP Iodine is provided in Table 7.

TABLE 7 --- PVP Iodine



The Iodine Wiper was evaluated under actual use conditions to determine if it would be effective in reducing microbial levels on human hands. As discussed previously, contamination from hands is one of the most likely sources of food microbial levels. The debate continues whether it is possible to thoroughly decontaminate or disinfect human skin. As a result, current food code regulations require that workers handling food wear gloves. Gloves become of increasing importance when workers either incorrectly wash their hands or avoid the practice altogether. Table 8 summarizes the results of a study on the handwashing habits of people using public washrooms sponsored by the Allegheny County, PA Department of Health.

TABLE 8 --- Handwashing Study

Washed hands properly	21% (male)	58% (female)
Wet hands only	33% (male)	25% (female)
Did nothing	46% (male)	17% (female)

With this level of contaminated hands, it seemed reasonable to consider the Iodine Wiper as a method to augment handwashing, especially when ungloved hands are used to handle food or as a backup system in the event of glove failure.

To test the Iodine Wiper, a group of subject volunteers who refrained from using topical antimicrobials for at least one week prior to testing were selected. The effectiveness of the Iodine Wiper as an antimicrobial agent was measured by comparing the number of marker bacteria --- *Serratia marcescens* --- recovered from artificially contaminated hands after use of the wiper to the number of bacteria recovered from contaminated untreated hands. The effectiveness of the wiper was measured after the 1<sup>st</sup>, 3<sup>rd</sup>, 5<sup>th</sup>, 7<sup>th</sup> and 10<sup>th</sup> contaminations. All contaminations/treatments occurred in the same day during a two hour period.

The Iodine Wiper treatment of each test subject followed the product instructions for use directions to "Rinse hands with water, then dry hands for 15 seconds using the iodine treated towel, wiping all skin surfaces on the hands including fingers and cuticles". The results of this experimentation is reported in Table 9.

TABLE 9 --- Iodine Wiper Evaluation

	Log Serratia count	Log Reduction	% Reduction
Mean Log <sub>10</sub> of Baseline Hands	9.1486	----	----
Mean Log <sub>10</sub> of Hands after 1 <sup>st</sup> Treatment	7.1050	2.1336	99.26
Mean Log <sub>10</sub> of Hands after 3 <sup>rd</sup> Treatment	6.8386	2.3100	99.51
Mean Log <sub>10</sub> of Hands after 5 <sup>th</sup> Treatment	6.7022	2.4464	99.64
Mean Log <sub>10</sub> of Hands after 7 <sup>th</sup> Treatment	6.7343	2.4143	99.61
Mean Log <sub>10</sub> of Hands after 10 <sup>th</sup> Treatment	6.8498	2.2988	99.49
Mean Log <sub>10</sub> of all Hands after Treatment	6.8280	2.3206	99.52

Review of the results of this testing indicates that the reductions in bacterial counts obtained through the use of the Iodine Wiper are similar to the reductions achieved through the use of Iodine-based liquid hand wash preparations.

## CONCLUSIONS

We have reviewed the need for increased levels of contamination control in food processing facilities. Particularly in light of increased public concern and a heightened regulatory environment, the most efficacious sanitation methods will be those that are viewed as being simple, convenient, reproducible and cost effective. This paper has discussed two methods, which can be implemented into existing control programs with dramatic reductions in microbial levels. Because both wiper systems may be used in a number of process, storage and packaging areas, implementation may be done throughout the facility or selectively at critical control points. Use of the Iodine Wiper should be considered in all restrooms, gowning and other break areas.

pace

ing Label and your address label

Tracking Label to the left of the address label

ur UPS Shipper Number or place parcel register tape above the address label


hipping Document

bill

*C100*  
*S.H.*  
*5/29*  
*11:15*

CONTEC INC.  
(864) 503-8333  
525 LOCUST GROVE RD.  
SPARTANBURG SC 29303

SHIP ATTN: DOCKETS MANAGEMENT BRANCH  
TO: FOOD AND DRUG ADMINISTRATION  
BRANCH HFA-305  
ROOM 1061  
5630 FISHERS LANE  
ROCKVILLE MD 20852




**MD 2070-10**



**UPS EARLY A.M.**

TRACKING #: 1Z 2X9 833 15 4573 8400

**1+**



Day Air Letter is to be used for document shipments only.

no limit on weight or the number of pages you may enclose.

visit our Web site at [www.ups.com](http://www.ups.com)

CONTEC TMMO 6 0.1814 E2543