
	ORA LABORATORY PROCEDURE Food and Drug Administration	Document No.: ORA-LAB. 5.8	Version No.: 1.5
			Page 1 of 7
Title: SAMPLE MANAGEMENT		Effective Date: 10-01-03 Revised: 05/02/14	

Section Included in this Document/(Change History)

1. Purpose
 2. Scope
 3. Responsibilities
 4. Background
 5. References
 6. Procedure/(added reference to LIMS to 6.1 A.& D.,6.2 B., C., & D., 6.3 A.)
 7. Definitions/(FACTS -deleted last sentence; added LIMS)
 8. Records/(added Electronic records)
 9. Supporting Documents/(add LIMS User's Manual)
 10. Attachments
- Document History

-
- 1. Purpose** This procedure describes how the laboratory receives, distributes, stores and disposes of samples.
-
- 2. Scope** This procedure applies to samples received by the laboratory.
-
- 3. Responsibilities**
- A. Laboratory Director or designated personnel is responsible for the overall control of samples in the Laboratory.
 - B. Sample Custodian and assigned back-up personnel are responsible for following the policies and procedures as outline in this procedure.
 - C. Compliance Officers of the Compliance Branch for the home district is responsible for authorizing disposition of samples. In the case of non-FDA samples, the requesting or collecting organization authorizes disposition.
-
- 4. Background** None
-
- 5. References** ISO/IEC 17025. *General requirements for the competence of testing and calibration laboratories* (5.8 Handling of Test and Calibration Items). Geneva, Switzerland: The International Organization for Standardization and the International Electrotechnical Commission.
-
- 6. Procedure** This procedure addresses the topics of sample receipt and processing, sample rejections, sample storage, sample transfers and analyst custody, sample shipping, and sample disposal.

	ORA LABORATORY PROCEDURE Food and Drug Administration	Document No.: ORA-LAB. 5.8	Version No.: 1.5
			Page 2 of 7
Title: SAMPLE MANAGEMENT			Effective Date: 10-01-03 Revised: 05/02/14

**6.1
Sample
Receipt and
Processing**

A. FDA Samples:

- Samples for the analyzing laboratory are received in a designated area (i.e. sample processing room).
- Agency samples delivered to the laboratory must have an associated Collection Report (C/R) in the Field Accomplishments and Compliance Tracking System (FACTS). FACTS, as well as the Laboratory Information Management System (LIMS), assigns sequentially an unique identification number which initiates sample tracking. Sample identification is described in the Investigations Operations Manual (IOM).

B. Other (Non-FDA) Samples:


For non-agency samples (e.g. State or USDA) delivered to the laboratory, unique identification and a corresponding Collection Report is generated in FACTS. The laboratory initiates sample tracking through FACTS in order to assign the unique identification number for the sample. Refer to the appropriate sections in the FACTS Manual to generate a C/R or to initiate sample tracking.

C. Samples Submitted for Storage Only:

Samples from non-FDA agencies for storage purposes only do not need to be entered into FACTS, but each laboratory records the same information (if provided), for sample storage and sample inventory purposes. The unique identifier would be the requesting or collecting agency's identification.

D. Sample Receipt and Processing:

1. Upon receipt of the sample, the following will be done:
 - a. The person who is authorized to receive the sample verifies that packages received are consistent with the description on the C/R.
 - b. He or she observes and records the condition of the sample and compares it with the electronic C/R for the following items: collector, analyzing organization, number of units, collection date, sample identification number, matrix and product identification, requested analyses, and storage conditions.

	ORA LABORATORY PROCEDURE Food and Drug Administration	Document No.: ORA-LAB. 5.8	Version No.: 1.5
			Page 3 of 7
Title: SAMPLE MANAGEMENT			Effective Date: 10-01-03 Revised: 05/02/14

-
- c. If a collection report and its samples are received and found to be incomplete, notify a supervisor or analyst.
 - d. Modifications or instructions are annotated in FACTS or LIMS.
 - e. The sample identification (ID) number on the sample container is cross referenced to the C/R.
 - f. If the sample ID does not match the request form sample ID, the sample is held pending clarification from the requestor. If clarification cannot be satisfactorily obtained, the samples are stored temporarily or returned.
 - g. If the sample is rejected, the reason for rejection is documented in FACTS, LIMS, or per local instructions. The sample may be returned to the collector.
2. Other information will also be checked and or verified such as:
- if applicable, presence of seal and seal integrity (NOTE: Seals are not needed on all samples. See the IOM, Section 4 for sample identification requirements);
 - seal quotation, including date and signature or initials are to be consistent with electronic C/R;
 - analysis requested (If an analysis is not performed by the receiving lab, the supervisor is contacted or local instructions are followed to forward to the designated analyzing laboratory.);
 - storage conditions in accordance with shipping (If not, the supervisor is contacted for clarification.); and
 - any records or documentation received with the sample are to accompany the sample and are included with the administrative package that accompanies the lab reporting of results.
3. Sample condition and acceptability is checked and documented. The following criteria are for determining the acceptance and rejection of samples:



Title:

SAMPLE MANAGEMENT


Effective Date:
10-01-03
Revised: 05/02/14

- a. If the physical condition of the sample container (e.g. visible damage, leakage, seals intact) is unacceptable, the sample is classified as a Class V. The collector is notified electronically.
 - b. If the sample is leaking, contain the leak and notify the local Industrial Hygienist or Supervisor in accordance with the laboratory's local procedure.
 - c. If the loss of sample because of incomplete or improper sealing (e.g. leakage of liquids from bottles, loss of particulate material from containers and improper sealing of bags) is unacceptable, the sample is classified as a Class V. The collector is notified verbally or electronically by a Supervisor, analyst or Sample Custodian.
 - d. Acceptable samples are logged into FACTS or LIMS. The following information at a minimum will be annotated: date received (FACTS or LIMS field defaults to date entered), condition of container, shipping information, seal quotes, where (city and state), storage location, and any comments in the special handling instruction field.
 - e. For samples received that are perishable or an urgent priority, the applicable section Supervisor or assigned analyst is notified.
4. Samples received not meeting the above criteria are considered for rejection. The Quality Management System Manager, laboratory management and Supervisors are the authorizing officials to determine whether samples are rejected. For samples that have been compromised (i.e. damaged, contaminated, or integrity questioned) the requestor is notified verbally or electronically with the nature of rejection and consulted on the course of action to take with his or her Supervisor. Further instructions are given by the Supervisor in conjunction with the client in order to process the sample. All communications are documented.

**6.2
Sample
Storage and
Sample
Transfer**

A. Sample Storage

1. Samples awaiting analyses are placed in the designated storage locations by the Sample Custodian in accordance with instructions received with the sample or from the Laboratory Supervisor.
2. Samples are stored frozen, refrigerated or at room temperature. Controlled drug substances are stored in a separate locked area (i.e.

	ORA LABORATORY PROCEDURE Food and Drug Administration	Document No.: ORA-LAB. 5.8	Version No.: 1.5
			Page 5 of 7
Title: SAMPLE MANAGEMENT		Effective Date: 10-01-03 Revised: 05/02/14	

safe).

3. The sample storage areas are organized to prevent contamination or cross contamination and are monitored. Each laboratory is to have a local procedure for monitoring the storage of samples.

B. Sample Transfers Within the Laboratory


1. Sample transfers between the Sample Custodian and analysts document the chain of custody. Samples received from the Sample Custodian are recorded in the web application, such as FACTS or LIMS, and documented on the handwritten worksheet or in the web application
2. Samples transferred between analysts are documented on the analytical worksheet and in FACTS or documented in LIMS, and described in Section 2, ORA-LAB.5.10 and local instructions.
3. Reserve portions of all samples are returned to the Sample Custodian unless documented on the handwritten analytical worksheet and in FACTS or documented in LIMS.

C. Sample Transfers Outside of the Laboratory

1. Samples or portions of samples transferred outside the laboratory are entered and accomplished in FACTS or LIMS.
2. The following information is documented and shows: (1) what was provided and how much, (2) how it was prepared for delivery, (3) how it was identified and sealed, (4) a brief explanation as to why the sample was sent, (5) to whom the sample was sent, and (6) the date of shipment. This is documented on the handwritten analyst worksheet and in FACTS or documented in LIMS.
3. Samples are shipped according to work instructions to ensure sample integrity and condition. Samples are shipped in accordance with Federal regulations.

D. Sample Storage During Analysis

1. Samples are kept under lock and key while in the analyst's possession.
2. If lockable storage is not obtainable or practical, the sample is returned to the Sample Custodian.

 ORA LABORATORY PROCEDURE Food and Drug Administration	Document No.: ORA-LAB. 5.8	Version No.: 1.5
	Page 6 of 7	
Title: SAMPLE MANAGEMENT		Effective Date: 10-01-03 Revised: 05/02/14

E. Sample Reserve Portions

1. Sample reserves are returned to the Sample Custodian upon completion of the analysis and documented on the handwritten worksheet and in FACTS or documented in LIMS.
2. The Sample Custodian will store the reserve in the designated storage area and under proper storage conditions.

**6.3
Sample
Disposition**

A. Sample Disposition

1. Authorization to dispose samples comes from the Compliance Officer, the Laboratory Director, or designated laboratory personnel through the Sample Disposition Notice (SDN). Under certain circumstance in accordance with the laboratory procedure, the analyst may dispose of a sample. In FACTS or LIMS this is an *in-house disposition* of the sample reserve.
2. If the *in-house disposition* is used, a local procedure or FMD 151 for disposition of BSE samples specifies under what circumstances and conditions the analyst may destroy the reserve. Examples where reserve samples may be destroyed by the analyst are: no reserve sample remains because the entire sample was consumed during analysis, the reserve is an import product with no action indicated (NAI) classification or perishable samples with NAI classification where the Supervisor has concurred with immediate destruction.
3. The analyst documents the in-house destruction of the reserve sample in FACTS or in LIMS.
4. Disposition of the sample is completed following receipt of the disposition authorization in FACTS or by memorandum in a timely manner. Date of disposal is documented in the web application, such as FACTS or LIMS.
5. Samples are disposed in accordance with Federal, State and local regulations.

**7.
Definitions**

FACTS - The Field Accomplishments and Compliance Tracking System (FACTS) is FDA's national operational database used to manage field work assignments, and record work results from assignment through compliance action. LIMS – Laboratory Information System (LIMS) is ORA's national



Title:
SAMPLE MANAGEMENT

Effective Date:
10-01-03
Revised: 05/02/14

laboratory database used to manage sample testing.

Sample accountability – This is a continuous record documenting that the sample's integrity has been preserved and demonstrates continuity of handling.

8. Records The following records document sample accountability:

- Collection Report
- Official Seal (FD-415a)
- Analyst Worksheet (FD-431 series)
- Electronic records

9. Supporting Documents FACTS Users Manual chapters or work instructions for:

- initiate sample tracking,
- sample transfers to analysts, and
- sample disposition.

LIMS User's Manual

Sample storage area work instructions

Field Management Directive (FMD) 151

10. Attachments None

Document History					
Version No.	Status (I, R, C)	Date Approved	Location of Change History	Name & Title	
				Author	Approving Official
1.2	R	11/16/05	In Document	LMEB	LMEB
1.3	R	08/15/08	In Document	LMEB	LMEB
1.4	R	01/11/11	In Document	LMEB	LMEB
1.5	R	05/08/14	In Document	LMEB	LMEB

Approving Official's signature: _____ Date: _____