



BIONETICS

Mutagenic Evaluation of Compound FDA 73-52
Inositol

MUTAGENIC EVALUATION OF
COMPOUND FDA 73-52
INOSITOL

5510 Nicholson Lane
Kensington, Maryland
20795

LBI PROJECT #2468

MUTAGENIC EVALUATION OF
COMPOUND FDA 73-52
INOSITOL

SUBMITTED TO

FOOD & DRUG ADMINISTRATION
DEPARTMENT OF HEALTH, EDUCATION AND WELFARE
ROCKVILLE, MARYLAND

SUBMITTED BY

LITTON BIONETICS, INC.
5516 NICHOLSON LANE
KENSINGTON, MARYLAND

DECEMBER 17, 1974



BIONETICS

TABLE OF CONTENTS

	<u>Page No.</u>
Evaluation Summary	1
I. Objective	2
II. Materials	2
III. Methods	3
IV. Solubility Properties	7
V. Toxicity and Dosage Determinations	8
VI. Non-activation Plate Tests	9
VII. Activation Plate Tests	11
VIII. Non-activation Suspension Tests/ <u>Salmonella</u>	17
IX. Activation Suspension Tests/ <u>Salmonella</u>	19
X. Non-activation Suspension Tests/ <u>Saccharomyces</u>	25
XI. Activation Suspension Tests/ <u>Saccharomyces</u>	27
XII. Summary of Test Results	35
XIII. Interpretation and Conclusions	41

Appendix - Summary of Tests Evaluating DMSO for Genetic
Activity in Salmonella and Saccharomyces



BIONETICS

EVALUATION SUMMARY

Compound FDA 73-52, Inositol, did not exhibit genetic activity in any of the in vitro assays included in this evaluation.



DATE: 12-17-74

SPONSOR: Food and Drug Administration, Contract Number 223-74-2104

SUBJECT: Mutagenic Evaluation of Compound FDA 73-52

I. OBJECTIVE

The objective of this study was to assess the genetic activity of the test material in microbial assays with and without the addition of mammalian metabolic enzyme preparations.

II. MATERIALS

A. Test Material

Inositol
A.E. Staley #E910

B. Tissue Homogenates and Supernatants

The tissue homogenates and 9,000 x g supernatants were prepared from liver, lung and testes of the following mammalian species: Mouse - ICR random bred adult males; rat - Sprague-Dawley adult males; and primate - Macaca mulatta adult males.

C. Indicator Organisms

The indicator organisms used for all tests are described below:

- Saccharomyces cerevisiae, strain D4: $\frac{\alpha}{a}$, $\frac{ade\ 2-2}{ade\ 2-1}$, $\frac{try\ 5-12}{try\ 5-27}$
- Salmonella typhimurium, strains:
 - TA-1535; hisG, uvrB, rfa (missense mutation)
 - TA-1537; hisC, uvrB, rfa (- frameshift mutation)
 - TA-1538; hisD, uvrB, rfa (+ frameshift mutation)

D. Reaction Mixture

The following reaction mixture was employed in the activation tests:



BIONETICS

<u>Component</u>	<u>Final Concentration/ml</u>
1. TPN (sodium salt)	6 μ M
2. Isocitric acid	49 μ M
3. Tris buffer, pH 7.4	28 μ M
4. MgCl ₂	1.7 μ M
5. Isocitric dehydrogenase	1.0 Unit
6. Tissue homogenate or cell fraction	72 mg

Components 1-4 were combined and frozen as a "core" reaction mixture to which the other components were added just prior to use.

E. Positive Control Compounds

Table 1 lists chemicals for positive controls in the direct and activation assays.

TABLE 1
POSITIVE CONTROLS USED IN DIRECT AND ACTIVATION ASSAYS

<u>ASSAY</u>	<u>CHEMICAL^a</u>	<u>SOLVENT</u>	<u>PROBABLE MUTAGENIC SPECIFICITY^b</u>
Non-activation	Ethylmethane sulfonate	Water or saline	BPS
	2-Nitrosofluorene	Dimethylsulfoxide ^c	FS
	Quinacrine or Quinacrine mustard	Water or saline	FS
Activation	Dimethylnitrosamine	Water or saline	BPS
	2-Acetylaminofluorene	Dimethylsulfoxide ^c	FS

^a Concentrations given in the Results Section.

^b BPS = base-pair substitution; FS = frameshift.

^c Previously shown to be non-mutagenic

III. METHODS

A. Toxicity

The solubility, toxicity and doses for all chemicals were determined prior to screening.

Each chemical was tested for survival against strains TA-1537 and D4 over a range of doses to determine the 50% survival dose. Bacteria were tested in phosphate buffer, pH 7.4, for one hour at 37°C on a shaker. Yeasts were tested in phosphate buffer, pH 7.4, for four hours at 30°C on a shaker. The 50% survival dose was determined from the survival curve and the 1/4 and 1/2 50% doses calculated.



BIONETICS

Litton

If no toxicity was obtained for a chemical with a given strain, then a maximum dose of 5% (w/v) was used against the strain.

Unless otherwise specified, the doses calculated for the tests in buffer were applied to the activation tests. The solubility of the test chemical under treatment conditions is stated in the Results Section.

B. Plate Tests

Only three bacteria strains were tested in qualitative plate tests. In the non-activation procedure, approximately 10^9 cells of a log phase culture of the bacterial indicator strains were spread over the surface of a minimal plate, and a measured amount of the test chemical was placed in the center of the test plate. In activation tests, the test chemical was added to the cells, and an aliquot of the mixture was spread on the surface of the test plate. The reaction mixture (0.1 ml) plus tissue extract was then spotted on the surface of the plate. Positive and solvent controls were included. All plates were incubated at 37°C for four days and then scored. Each compound (Test, Positive Control and Solvent Control) was done in duplicate. The results were scored as + or -. Concentrations of the positive control compounds are listed in the Results Section.

C. Suspension Tests

1. Non-activation

Log-phase bacteria and stationary-phase yeast cultures of the indicator organisms were grown in complete broth, washed and resuspended in 0.9% saline to densities of 1×10^9 cells/ml and 5×10^7 cells/ml, respectively. This constituted the working stock for tests of a group of test chemicals and their respective controls. Tests were conducted in 30 ml plastic tissue culture flasks. Cells plus appropriate volume(s) of the test chemical were added to the flasks to give a final volume of 2 ml. Solvent replaced the test chemical in the negative controls. Treatment was at 30°C for four hours for yeast tests and at 37°C for one hour for bacterial tests. All flasks were shaken during treatment. Following treatment, the flasks were set in ice. Aliquots of cells were removed, diluted in sterile saline (4°C) and plated on the appropriate complete media. Undiluted samples from flasks containing the bacteria were plated on minimal selective medium. Samples from a 10^{-1} dilution of treated cells were plated on the selected media for enumeration of gene conversion with strain D4. Bacterial plates were scored after incubation for 48 hours at 37°C. The yeast plates were incubated at 30°C for 3-5 days before scoring.

2. Activation

Bacteria and yeast cells were grown and prepared as described in the non-activation tests except that the cell densities were increased approximately five-fold for working stock suspensions. Measured amounts of the test and



control chemicals plus 0.25 ml of the stock cell suspension were added to a 30 ml plastic tissue homogenate. All flasks (bacteria and yeast) were incubated at 37°C with shaking. The treatment times as well as the dilutions, plating procedures and scoring of the plates were the same as described for non-activation tests.

D. Preparation of Tissue Homogenates and 9,000 x g Cell Fractions

1. Mice

Male mice (sufficient to provide the necessary quantities of organs for testes, lung and liver homogenates) were killed by cranial blow, decapitated and bled. The three organs were immediately dissected from the animal using aseptic techniques and placed in ice-cold 0.25 M sucrose buffered with Tris at pH of 7.4. Upon collection of the desired quantity of organs, they were washed twice with fresh buffered sucrose and completely homogenized with a motor-driven homogenizing unit at 4°C. The whole organ homogenate obtained from this step was divided into two samples. One sample was frozen at -80°C and the other was centrifuged for 20 minutes at 9,000 x g in a refrigerated centrifuge. The supernatant from the centrifuged sample was retained and frozen at -80°C. These two frozen samples were used for the activation studies.

2. Rats

The same procedure as described for mice was used for this mammal.

3. Primates

The liver, lungs and testes were aseptically removed from freshly killed adult male rhesus (*M. mulatta*) monkeys. Each organ was cut into a number of pieces each sufficient for one week's studies. The tissues were labeled and frozen at -80°C until needed. Tissue homogenates and 9,000 x g supernatants were prepared as described for mice.

E. Data Recording and Reporting

Following the specified incubation periods all population plates were scored by an automatic colony counter and the results from each plate of a set were recorded, in ink, in bound data books. Information necessary for identification of the specific experiment as well as the presence of any contaminant microorganisms was recorded with each set of plate counts. All minimal or other types of selective media plates were hand scored and the results recorded along with the respective population data. For bacteria strains the number of colonies recorded from either the population or selective plates represents that number in 1 ml of test suspension plated. The numbers recorded for the yeast strain D4 represent the number in 0.5 ml of test suspension plated.



Frequencies were mechanically calculated and double checked. All data presented in the Results Section of this report consists of the actual sum of all raw data plate counts and only the frequencies are calculated figures.



IV. SOLUBILITY PROPERTIES OF THE TEST COMPOUND

1. NAME OR DESCRIPTION OF TEST COMPOUND:

FDA 73-52

Inositol A.E. Staley #E910

2. TEST SOLVENT AND DESCRIPTION OF SOLUBILITY
OF THE TEST CHEMICAL UNDER TREATMENT

CONDITIONS:

Stock solutions of this chemical were prepared in phosphate buffer, ph 7.4. The compound was completely soluble at all treatment concentrations.

3. OTHER COMMENTS:

Project No. 2468



BIONETICS

V. TOXICITY AND DOSAGE DETERMINATIONS

COMPOUND FDA 73-52

	D4	TA-1537
	Dose No.	% Concentration
Range of concentrations of the test compound used to determine the 50% survival level	1	0.1
	2	0.5
	3	1.0
	4	2.5
	5	5.0
	Dose No.	% Survival
Survival Results	Control	100
Test Date: <u>8-13-74</u>	1	100
	2	100
	3	100
	4	100
	5	93
	Dose	% Concentration
Concentrations of the test chemical required for mutagenicity tests	Plate Test	5.0
	$\frac{1}{4}$ 50% Survival	-
	$\frac{1}{2}$ 50% Survival	-
	Other	H 5.0 L 2.5

Project No. 2468

VI. NON-ACTIVATION PLATE TESTS

DATE: 9-19-74

Test	Compound	Concentration/plate	<u>TA-1535</u>		<u>TA-1537</u>		<u>TA-1538</u>	
			T-1	T-2	T-1	T-2	T-1	T-2
PC	EMS	0.05 ml undiluted chemical	>10 ³	>10 ³				
	QM	0.25 mg			56	43		
	NF	0.25 mg					25	31
SC	SALINE	-	3	0	3	4		
	DMSO	<10%					3	5

NOTE: PC = positive control
 SC = solvent control
 T-1 = trial 1
 T-2 = trial 2
 EMS = ethyl methanesulfonate
 QM = quinacrine mustard
 NF = nitrosofluorene
 DMSO = dimethyl sulfoxide
 (c) = contamination present

Project No. 2468

NON-ACTIVATION PLATE TESTS

DATE: 9-19-74

Test	Compound	Concentration	<u>TA-1535</u>		<u>TA-1537</u>		<u>TA-1538</u>	
			T-1	T-2	T-1	T-2	T-1	T-2
TC	FDA 73-52	5.0%	3	2	6	26	2	1

NOTE: TC = test compound
T-1 = trial 1
T-2 = trial 2
(c) = contamination present

Project No. 2468

VII. . . ACTIVATION PLATE TESTS



BIONETICS

SPECIES: Mouse

DATE: 9-19-74

Test	Organ	Compound	Concentration/plate	<u>TA-1535</u>		<u>TA-1537</u>		<u>TA-1538</u>	
				T-1	T-2	T-1	T-2	T-1	T-2
PC	Li	DMNA	25 μ moles	>10 ²	>10 ²				
		AAF	1.25 mg			>10 ²	>10 ²	>10 ²	>10 ²
	Lu	DMNA	25 μ moles	7	3				
		AAF	1.25 mg			17	18	45	35
	T	DMNA	25 μ moles	(c)	5				
		AAF	1.25 mg			23	16	16	13
SC	-	DMNA	25 μ moles	3	4				
	-	AAF	1.25 mg			15	19	17	14
	-	Saline	-	3	4				
	-	DMSO	<10%			12	14	15	13

NOTE: PC = positive control
 SC = solvent and chemical controls
 AAF = 2-acetylaminofluorene
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung

T = testes
 T-1 = trial 1
 T-2 = trial 2
 DMSO = dimethyl sulfoxide
 (c) = contamination present

Project No. 2468



BIONETICS

ACTIVATION PLATE TESTS

SPECIES: Mouse

DATE: 9-19-74

Test	Organ	Compound	Concentration	TA-1535		TA-1537		TA-1538			
				T-1	T-2	T-1	T-2	T-1	T-2		
TC	Li	FDA 73-52	5.0%	4	4		14	17		15	27
	Lu	FDA 73-52	5.0%	4	4		8	8		35	35
	T	FDA 73-52	5.0%	3	7		21	28		31	20

NOTE: TC = test compound
Li = liver
Lu = lung
T = testes
T-1 = trial 1
T-2 = trial 2
(c) = contamination present

Project No. 2468

ACTIVATION PLATE TESTS

LITTON

BIONETICS

DATE: 9-19-74

SPECIES: Rat

Test	Organ	Compound	Concentration/plate	TA-1535		TA-1537		TA-1538	
				T-1	T-2	T-1	T-2	T-1	T-2
PC	Li	DMNA	25 μ moles	10 ²	>10 ²				
		AAF	1.25 mg			>10 ²	>10 ²	>10 ²	>10 ²
	Lu	DMNA	25 μ moles	2	3				
		AAF	1.25 mg			17	8	28	20
	T	DMNA	25 μ moles	3	6				
		AAF	1.25 mg			7	8	14	9
SC	-	DMNA	25 μ moles	3	4				
	-	AAF	1.25 mg			15	19	17	14
	-	Saline	-	3	4				
	-	DMSO	<10%			12	14	15	13

NOTE: PC = positive control
 SC = solvent and chemical controls
 AAF = 2-acetylaminofluorene
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung

T = testes
 T-1 = trial 1
 T-2 = trial 2
 DMSO = dimethyl sulfoxide
 (c) = contamination present

Project No. 2468

ACTIVATION PLATE TESTS

SPECIES: Rat

DATE: 9-19-74

Test	Organ	Compound	Concentration	<u>TA-1535</u>		<u>TA-1537</u>		<u>TA-1538</u>	
				T-1	T-2	T-1	T-2	T-1	T-2
TC	Li	FDA 73-52	5.0%	4	4	27	24	23	28
	Lu	FDA 73-52	5.0%	3	5	5	15	23	24
	T	FDA 73-52	5.0%	5	5	10	18	24	40

NOTE: TC = test compound
 Li = liver
 Lu = lung
 T = testes
 T-1 = trial 1
 T-2 = trial 2
 (c) = contamination present

Project No. 2468

ACTIVATION PLATE TESTS



BIONETICS

SPECIES: Monkey

DATE: 9-19-74

Test	Organ	Compound	Concentration/plate	TA-1535		TA-1537		TA-1538	
				T-1	T-2	T-1	T-2	T-1	T-2
PC	Li	DMNA	25 μ moles	>10 ²	>10 ²				
		AAF	1.25 mg			>10 ²	>10 ²	>10 ²	>10 ²
	Lu	DMNA	25 μ moles	3	4				
		AAF	1.25 mg			10 ⁻⁷	8	13	10
	T	DMNA	25 μ moles	3	3				
		AAF	1.25 mg			10	7	11	11
SC	-	DMNA	25 μ moles	3	4				
	-	AAF	1.25 mg			15	19	17	14
	-	Saline	-	3	4				
	-	DMSO	<10%			12	14	15	13

NOTE: PC = positive control
 SC = solvent and chemical controls
 AAF = 2-acetylaminofluorene
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung

T = testes
 T-1 = trial 1
 T-2 = trial 2
 DMSO = dimethyl sulfoxide
 (c) = contamination present

Project No. 2468

ACTIVATION PLATE TESTS

SPECIES: Monkey

DATE: 9-19-74

Test	Organ	Compound	Concentration	<u>TA-1535</u>		<u>TA-1537</u>		<u>TA-1538</u>	
				T-1	T-2	T-1	T-2	T-1	T-2
TC	Li	FDA 73-52	5.0%	4	0			10	13
	Lu	FDA 73-52	5.0%	6	3			4	9
	T	FDA 73-52	5.0%	4	3			7	16
								17	8
								14	23
								18	20

NOTE: TC = test compound
 Li = liver
 Lu = lung
 T = testes
 T-1 = trial 1
 T-2 = trial 2
 (c) = contamination present

Project No. 2468

VIII. NON-ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS:
POSITIVE AND SOLVENT CONTROL RESULTS

DATE: 9-8-74

Test	Indicator Strain	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	TA-1535	EMS	0.05 %	2.96	1,790	604.73
	TA-1537	QM	0.01 mg/ml	3.11	911	292.93
	TA-1538	NF	1.25 mg/ml	3.66	266	72.68
SC	TA-1535	SALINE	-	3.27	6	1.83
	TA-1537	SALINE	-	4.66	37	7.94
	TA-1538	DMSO	-	3.01	13	4.32

NOTE: PC = positive control
 SC = solvent control
 EMS = ethyl methanesulfonate
 QM = quinacrine mustard
 NF = nitrofluorene
 DMSO = dimethyl sulfoxide
 (c) = contamination present

2468



BIONETICS

NON-ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS

DATE: 9-08-74

Test	Indicator Strain	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
TC	TA-1535	FDA 73-52	H	2.62 (80)	5	1.91
TC	TA-1535	FDA 73-52	L	3.22 (98)	6	1.86
TC	TA-1537	FDA 73-52	H	7.41 (159)	23	3.10
TC	TA-1537	FDA 73-52	L	11.49 (247)	46	4.00
TC	TA-1538	FDA 73-52	H	3.06 (102)	26	8.50
TC	TA-1538	FDA 73-52	L	2.91 (97)	31	10.65

NOTE: TC = test compound
H = high dose
L = low dose
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

IX. ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: Mouse

DATE: 9-10-74				Strain TA-1535		
Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	DMNA	100 μ moles/ml	4.11	4,449	1082.48
	Lu	DMNA	100 μ moles/ml	2.59	24	9.27
	T	DMNA	100 μ moles/ml	4.14	22	5.31
SC	-	DMNA	100 μ moles/ml	3.37	6	1.78
	-	SALINE	-	3.84	8	2.08

DATE: 9-23-74				Strain TA-1537		
Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	4.64	80	17.24
	Lu	AAF	1.25 mg/ml	5.76	10	1.74
	T	AAF	1.25 mg/ml	5.04	22	4.37
SC	-	AAF	1.25 mg/ml	5.24	41	7.82
	-	DMSO	-	6.01	41	6.82

DATE: 9-24-74 (Repeated Compounds)				Strain TA-1538		
Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	4.26	181	42.49
	Lu	AAF	1.25 mg/ml	2.04	7	3.43
	T	AAF	1.25 mg/ml	3.55	6	1.70
SC	-	AAF	1.25 mg/ml	1.46	24	16.44
	-	DMSO	-	2.85	37	12.98

NOTE: PC = positive control
SC = solvent and chemical controls (c) = contamination present
AAF = 2-acetylaminofluorene
DMNA = dimethylnitrosamine
Li = liver
Lu = lung
T = testes
DMSO = dimethyl sulfoxide

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS

SPECIES: Mouse

DATE: 9-10-74

Strain TA-1535

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
TC	Li	FDA 73-52	H	3.46 (90)	17	4.91
			L	3.21 (84)	22	6.85
	Lu	FDA 73-52	H	(c)1.87 (49)	6 (c)	3.21
			L	2.60 (68)	7	2.69
	T	FDA 73-52	H	3.96 (103)	21	5.30
			L	3.16 (82)	13	4.11

DATE: 9-23-74

Strain TA-1537

TC	Li	FDA 73-52	H	4.26 (71)	15	3.52
			L	2.37 (39)	23	9.71
	Lu	FDA 73-52	H	4.33 (72)	9	2.08
			L	3.69 (61)	21	5.69
	T	FDA 73-52	H	3.16 (53)	18	5.70
			L	3.08 (51)	40	12.99

DATE: 9-24-74

Strain TA-1538

TC	Li	FDA 73-52	H	3.37 (118)	38	11.28
			L	2.70 (95)	32	11.85
	Lu	FDA 73-52	H	2.74 (96)	22	8.03
			L	2.57 (90)	19	7.39
	T	FDA 73-52	H	2.66 (93)	27	10.15
			L	2.97 (104)	22	7.41

NOTES: H = high dose
L = low dose
TC = test compound
Li = liver
Lu = lung
T = testes
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: RAT

DATE: 9-13-74

Strain TA-1535

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	DMNA	100 μ moles/ml	3.83	1,342	350.39
	Lu	DMNA	100 μ moles/ml	4.34	9	2.07
	T	DMNA	100 μ moles/ml	3.39	15	4.43
SC	-	DMNA	100 μ moles/ml	3.14	5	1.59
	-	SALINE	-	4.13	7	1.70

DATE: 9-25-74

Strain TA-1537

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	4.93	146	29.62
	Lu	AAF	1.25 mg/ml	5.15	64	12.43
	T	AAF	1.25 mg/ml	4.87	79	16.22
SC	-	AAF	1.25 mg/ml	6.30	110	17.46
	-	DMSO	-	6.93	67	9.67

DATE: 9-24-74

Strain TA-1538

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	3.26	137	42.02
	Lu	AAF	1.25 mg/ml	3.18	33	10.38
	T	AAF	1.25 mg/ml	2.30	37	16.09
SC	-	AAF	1.25 mg/ml	1.46	24	16.44
	-	DMSO	-	2.85	37	12.98

NOTE: PC = positive control
 SC = solvent and chemical controls (c) = contamination present
 AAF = 2-acetylaminofluorene
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes
 DMSO = dimethyl sulfoxide

Project No. 2468

**ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS**

SPECIES: Rat

DATE: 9-13-74

Strain TA-1535

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
TC	Li	FDA 73-52	H	3.01 (73)	4	1.33
			L	3.06 (74)	8	2.61
	Lu	FDA 73-52	H	3.43 (83)	5	1.46
			L	2.63 (64)	4	1.52
	T	FDA 73-52	H	2.08 (50)	10	4.81
			L	2.95 (71)	9	3.05

DATE: 9-25-74

Strain TA-1537

TC	Li	FDA 73-52	H	6.70 (97)	77	11.49
			L	3.71 (54)	29	7.82
	Lu	FDA 73-52	H	4.02 (58)	99	24.63
			L	7.29 (105)	115	15.78
	T	FDA 73-52	H	3.97 (57)	56	14.11
			L	3.65 (53)	54	14.79

DATE: 9-24-74

Strain TA-1538

TC	Li	FDA 73-52	H	2.76 (97)	37	13.41
			L	3.79 (133)	37	9.76
	Lu	FDA 73-52	H	0.85 (30)	6	7.06
			L	0.73 (27)	13	17.81
	T	FDA 73-52	H	1.69 (59)	6	3.55
			L	2.87 (101)	27	9.41

NOTES: H = high dose
 L = low dose
 TC = test compound
 Li = liver
 Lu = lung
 T = testes
 (c) = contamination present
 () = percent survival

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: MONKEY

DATE: 10-1-74

Strain TA-1535

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	DMNA	100 μ moles/ml	5.33	1,600	300.19
	Lu	DMNA	100 μ moles/ml	5.91	10	1.69
	T	DMNA	100 μ moles/ml	5.91	5	0.85
SC	-	DMNA	100 μ moles/ml	4.24	9	2.12
	-	SALINE	-	5.24	9	1.72

DATE: 9-25-74

Strain TA-1537

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	3.90	95	24.36
	Lu	AAF	1.25 mg/ml	2.95	22	7.46
	T	AAF	1.25 mg/ml	5.29	28	5.29
SC	-	AAF	1.25 mg/ml	3.18	25	7.86
	-	DMSO	-	2.66	15	5.64

DATE: 10-4-74

Strain TA-1538

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
PC	Li	AAF	1.25 mg/ml	6.50	197	30.31
	Lu	AAF	1.25 mg/ml	6.87	86	12.52
	T	AAF	1.25 mg/ml	4.36	69	15.83
SC	-	AAF	1.25 mg/ml	4.90	84	17.14
	-	DMSO	-	5.55	71	12.79

NOTE: PC = positive control
 SC = solvent and chemical controls
 AAF = 2-acetylaminofluorene
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes
 DMSO = dimethyl sulfoxide

(c) = contamination present

Project No. 2468



BIONETICS

Litton

ACTIVATION SUSPENSION TESTS
WITH SALMONELLA INDICATOR STRAINS

SPECIES: Monkey

DATE: 10-01-74

Strain TA-1535

Test	Organ	Compound	Concentration	Total Cells/ mlx10 ⁸	his+ Revertants/ ml	his+ Revertants/10 ⁸ Survivors
TC	Li	FDA 73-52	H	4.36 (83)	7	1.61
			L	4.47 (85)	4	0.90
	Lu	FDA 73-52	H	(c)4.20 (80)	7	1.67
			L	4.64 (89)	5	1.08
	T	FDA 73-52	H	4.50 (86)	7	1.56
			L	4.72 (90)	5	1.06

DATE: 9-25-74

Strain TA-1537

TC	Li	FDA 73-52	H	3.59 (135)	9	2.51
			L	5.66 (213)	18	3.18
	Lu	FDA 73-52	H	4.85 (182)	14	2.90
			L	4.72 (177)	14	2.97
	T	FDA 73-52	H	4.34 (163)	18	4.15
			L	4.09 (156)	11	2.69

DATE: 10-04-74

Strain TA-1538

TC	Li	FDA 73-52	H	4.16 (75)	71	17.07
			L	5.01 (90)	75	14.97
	Lu	FDA 73-52	H	7.09 (128)	73	10.30
			L	7.37 (133)	67	9.09
	T	FDA 73-52	H	7.50 (135)	42	5.60
			L	5.47 (99)	81	14.81

NOTES: H = high dose
 L = low dose
 TC = test compound
 Li = liver
 Lu = lung
 T = testes
 (c) = contamination present
 () = percent survival

Project No. 2468



BIONETICS

X. NON-ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

DATE: 9-16-74

Strain D4							
Test	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
				Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
PC	EMS	1.0 %	6.94	189	271	27.23	39.05
SC	Saline	-	7.69	27	38	3.51	4.94

NOTE: PC = positive control
 SC = solvent control
 EMS = ethyl methanesulfonate
 a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present

Project No. 2468



BIONETICS

NON-ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

DATE: 9-16-74

Strain D4							
Test	Compound	Concentration	Total Population Screened ^a	Number Convertants ^b		Convertants 10 ⁵ Ade ⁺	Per Survivors Try ⁺
TC	FDA 73-52	H	5.87 (76)	30	24	5.11	4.09
	FDA 73-52	L	6.44 (84)	25	25	3.88	3.88

NOTE: TC = test compound
 H = high dose
 L = low dose
 a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present
 () = percent survival

Project No. 2468



BIONETICS

XI. ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: Mouse

DATE: 9-19-74

				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
PC	Li	DMNA	150 μ moles/ml	5.16	82	77	15.89	14.92
	Lu	DMNA	150 μ moles/ml	4.93	13	10	2.64	2.03
	T	DMNA	150 μ moles/ml	5.10	11	6	2.16	1.18
SC	-	DMNA	150 μ moles/ml	6.51	20	26	3.07	3.99
	-	SALINE	-	6.47	37	22	5.72	3.40

NOTE: PC = positive control
 SC = solvent and chemical controls
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes

 a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present

Project No. 2468



BIONETICS

Litton

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

SPECIES: Mouse

DATE: 9-19-74

				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Conyertants ^b		Conyertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
TC	Li	FDA 73-52	H	6.13 (95)	25(c)	18	4.08	2.94
			L	5.79 (89)	22	19	3.80	3.28
	Lu	FDA 73-52	H	4.24 (66)	24	31	5.66	7.31
			L	6.72 (104)	23	24	3.42	3.57
	T	FDA 73-52	H	4.42 (68)	29	16	6.56	3.62
			L	6.85 (106)	32(c)	19(c)	4.67	2.77

NOTE:

TC = test compound
H = high dose
L = low dose
Li = liver
Lu = lung
T = testes
a = number x 10⁵
b = number at 10⁻¹ dilution
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: Rat

DATE: 10-18-74

High Dose				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
PC	Li	DMNA	150 µmoles/ml	7.93	78	75	9.84	9.46
	Lu	DMNA	150 µmoles/ml	7.99	33	27	4.13	3.37
	T	DMNA	150 µmoles/ml	9.03	36 (c)	31 (c)	3.99	3.43
SC	-	DMNA	150 µmoles/ml	8.74	42 (c)	31 (c)	4.81	3.55
	-	SALINE	-	7.13 (c)	43 (c)	24	6.03	3.37

NOTE: PC = positive control
 SC = solvent and chemical controls
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes

a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present

Project No. 2468



BIONETICS

Litton

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

SPECIES: Rat

DATE: 10-18-74

High Dose				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Conyertants ^b		Conyertants Per 10 ⁵ Survivors Ade ⁺	Try ⁺
TC	Li	FDA 73-52	H	5.81 (81)	37	36	6.37	6.20
			L					
	Lu	FDA 73-52	H	6.08 (85)	26	34	4.28	5.59
			L					
	T	FDA 73-52	H	6.16 (86)	47	33	7.63	5.36
			L					

NOTE:

TC = test compound
H = high dose
L = low dose
Li = liver
Lu = lung
T = testes
a = number x 10⁵
b = number at 10⁻¹ dilution
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: Rat

DATE: 9-26-74

Low Dose				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
PC	Li	DMNA	150 μ moles/ml	5.85	73	70	12.48	11.97
	Lu	DMNA	150 μ moles/ml	5.81	31	11	5.34	1.89
	T	DMNA	150 μ moles/ml	5.00	32	19	6.40	3.80
SC	-	DMNA	150 μ moles/ml	5.27	31	23	5.88	4.36
	-	SALINE	-	5.50	28	20	5.09	3.64

NOTE: PC = positive control
 SC = solvent and chemical controls
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes

a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present

Project No. 2468



BIONETICS

Litton

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

SPECIES: Rat

DATE: 9-26-74

Low Dose				Strain D4				
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Conyertants ^b		Conyertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
TC	Li	FDA 73-52	H					
			L	5.14 (93)	22	12	4.28	2.34
	Lu	FDA 73-52	H					
			L	5.18 (94)	22	11	4.25	2.12
	T	FDA 73-52	H					
			L	3.53 (64)	16	25(c)	4.53	7.08

NOTE: TC = test compound
H = high dose
L = low dose
Li = liver
Lu = lung
T = testes
a = number x 10⁵
b = number at 10⁻¹ dilution
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4:
POSITIVE AND SOLVENT CONTROL RESULTS

SPECIES: Monkey

DATE: 10-22-74

					Strain D4			
Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
PC	Li	DMNA	150 μ moles/ml	5.88	68	67	11.56	11.39
	Lu	DMNA	150 μ moles/ml	5.26	30	28	5.70	5.32
	T	DMNA	150 μ moles/ml	5.85	31	40	5.30	6.83
SC	-	DMNA	150 μ moles/ml	4.89	27	44	5.52	9.00
	-	SALINE	-	4.14	34	35	7.95	8.21

NOTE: PC = positive control
 SC = solvent and chemical controls
 DMNA = dimethylnitrosamine
 Li = liver
 Lu = lung
 T = testes

a = number x 10⁵
 b = number at 10⁻¹ dilution
 (c) = contamination present

Project No. 2468



BIONETICS

ACTIVATION SUSPENSION TESTS
WITH SACCHAROMYCES INDICATOR STRAIN D4

SPECIES: Monkey

DATE: 10-22-74

Strain D4

Test	Organ	Compound	Concentration	Total Population Screened ^a	Number of Convertants ^b		Convertants Per 10 ⁵ Survivors	
					Ade ⁺	Try ⁺	Ade ⁺	Try ⁺
TC	Li	FDA 73-52	H	5.48 (132)	28	33	5.11	6.02
		FDA 73-52	L	7.18 (173)	31(c)	56(c)	4.32	7.80
	Lu	FDA 73-52	H	4.17 (101)	32	24	7.67	5.76
		FDA 73-52	L	7.62 (184)	20(c)	95(c)	2.62	12.47
	T	FDA 73-52	H	4.21 (102)	31	33(c)	7.36	7.82
		FDA 73-52	L	6.74 (163)	25	36	3.71	5.34

NOTE:

TC = test compound
H = high dose
L = low dose
Li = liver
Lu = lung
T = testes
a = number x 10⁵
b = number at 10⁻¹ dilution
(c) = contamination present
() = percent survival

Project No. 2468



BIONETICS

XII. SUMMARY OF TEST RESULTS

COMPOUND FDA 73-52

A. Suspension Tests

Test ^a	Activation		Salmonella Reversion Frequencies (x 10 ⁻⁸)			Saccharomyces D4 Conversion Frequencies (x 10 ⁻⁵)	
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538	Ade ⁺	Try ⁺
NA-PC	-	-	604.73	292.93	72.68	27.23	39.05
NA-NC	-	-	1.83	7.94	4.32	3.51	4.94
NA-H	-	-	1.91	3.10	8.50	5.11	4.09
NA-L	-	-	1.86	4.00	10.65	3.88	3.88
A-NC (-C)	-	-	2.08	6.82	12.98	5.72	3.40
A-NC (+C)	-	-	1.78	7.82	16.44	3.07	3.99
A-PC	M	Li	1082.48	17.24	42.49	15.89	14.92
A-PC	M	Lu	9.27	1.74	3.43	2.64	2.03
A-PC	M	T	5.31	4.37	1.70	2.16	1.18
A-H	M	Li	4.91	3.52	11.28	4.08	2.94
A-L	M	Lu	6.85	9.71	11.85	3.80	3.28
A-H	M	Lu	3.21	2.08	8.03	5.66	7.31
A-L	M	T	2.69	5.69	7.39	3.42	3.57
A-L			5.30	5.70	10.15	6.56	3.62
			4.11	12.99	7.41	5.94	4.67

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

Project 2468

COMPOUND FDA 73-52

B. Plate Tests

Test ^a	<u>Activation</u>		<u>Salmonella Responses</u>		
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538
NA-PC	-	-	+	+	+
NA-NC	-	-	-	-	-
NA-H	-	-	-	-	-
A-NC (-C)	-	-	-	-	-
A-NC (+C)	-	-	-	-	-
A-PC	M	Li	+	+	+
A-PC	M	Lu	-	-	-
A-PC	M	T	-	-	-
A-H	M	Li	-	-	-
A-H	M	Lu	-	-	-
A-H	M	T	-	-	-

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

Project. 2468

SUMMARY OF TEST RESULTS

COMPOUND FDA 73-52

A. Suspension Tests

Test ^a	<u>Activation</u>		<u>Salmonella Reversion Frequencies (x 10⁻⁸)</u>			<u>Saccharomyces D4 Conversion Frequencies (x 10⁻⁵)</u>			
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538	Ade ⁺		Try ⁺	
NA-PC	-	-							
NA-NC	-	-							
NA-H	-	-							
NA-L	-	-							
<hr/>									
A-NC (-C)	-	-	1.70	9.67	12.98	L 5.09	H 6.03	L 3.64	H 3.37
A-NC (+C)	-	-	1.59	17.46	16.44	5.88	4.81	4.36	3.55
A-PC	R	Li	350.39	29.62	42.02	12.48	9.84	11.97	9.46
A-PC	R	Lu	2.07	12.43	10.38	5.34	4.13	1.89	3.37
A-PC	R	T	4.43	16.22	16.09	6.40	3.99	3.80	3.43
<hr/>									
A-H	R	Li	1.33	11.49	13.41	6.37		6.20	
A-L	R		2.61	7.82	9.76	4.28		2.34	
A-H	R	Lu	1.46	24.63	7.06	4.28		5.59	
A-L	R		1.52	15.78	17.81	4.25		2.12	
A-H	R	T	4.81	14.11	3.55	7.63		5.36	
A-L	R		3.05	14.79	9.41	4.53		7.08	

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

Project 2468

COMPOUND FDA 73-52

B. Plate Tests

Test ^a	<u>Activation</u>		<u>Salmonella Responses</u>		
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538
NA-PC	-	-			
NA-NC	-	-			
NA-H	-	-			
A-NC (-C)	-	-	-	-	-
A-NC (+C)	-	-	-	-	-
A-PC	R	Li	+	+	+
A-PC	R	Lu	-	-	-
A-PC	R	T	-	-	-
A-H	R	Li	-	-	-
A-H	R	Lu	-	-	-
A-H	R	T	-	-	-

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

Project , 2468

SUMMARY OF TEST RESULTS

COMPOUND FDA 73-52

A. Suspension Tests

Test ^a	Activation		Salmonella Reversion Frequencies (x 10 ⁻⁸)			Saccharomyces D4 Conversion Frequencies (x 10 ⁻⁵)	
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538	Ade ⁺	Try ⁺
NA-PC	-	-					
NA-NC	-	-					
NA-H	-	-					
NA-L	-	-					
A-NC (-C)	-	-	1.72	5.64	12.79	8.45	8.21
A-NC (+C)	-	-	2.12	7.86	17.14	5.52	9.00
A-PC	Mo	Li	300.19	24.36	30.31	11.56	11.39
A-PC	Mo	Lu	1.69	7.46	12.52	5.70	5.32
A-PC	Mo	T	0.85	5.29	15.83	5.30	6.84
A-H	Mo	Li	1.61	2.51	17.07	5.11	6.02
A-L	Mo		0.90	3.18	14.97	4.32	7.80
A-H	Mo	Lu	1.67	2.90	10.30	7.67	5.76
A-L	Mo		1.08	2.97	9.09	2.62	12.47
A-H	Mo	T	1.56	4.15	5.60	7.36	7.82
A-L	Mo		1.06	2.69	14.81	3.71	5.34

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

Project 2468

B. Plate Tests

Test ^a	Activation		Salmonella Responses		
	Species ^b	Organ ^c	TA-1535	TA-1537	TA-1538
NA-PC	-	-			
NA-NC	-	-			
NA-H	-	-			
A-NC (-C)	-	-	-	-	-
A-NC (+C)	-	-	-	-	-
A-PC	Mo	Li	+	+	+
A-PC	Mo	Lu	-	-	-
A-PC	Mo	T	-	-	-
A-H	Mo	Li	-	-	-
A-H	Mo	Lu	-	-	-
A-H	Mo	T	-	-	-

^a NA = non activation
 NC = negative control
 PC = positive control
 A = activation
 H = high dose
 L = low dose

^b M = mouse
 Mo = monkey
 R = rat

^c Li = liver
 Lu = lung
 T = testes

(-C) = solvent control
 (+C) = chemical control

XIII. INTERPRETATION AND CONCLUSIONS

Compound FDA 73-52, Inositol, was evaluated for genetic activity in a series of in vitro microbial assays with and without metabolic activation. The following results were obtained.

A. Salmonella typhimurim

1. Plate Tests

At a concentration of 5.0% (w/v), this compound was not mutagenic for TA-1535, TA-1537 or TA-1538.

2. Non-activation Suspension Tests

These tests were all negative.

3. Activation Suspension Tests

These tests were all negative. The high dose with rat lung produced an elevated reversion frequency with strain TA-1537. Because this increase was not supported by responses at any other dose levels or the plate tests, it was considered to be aberrant. Part of the problem might also be a result of the low positive control response for TA-1537 in this test.

B. Saccharomyces cerevisiae

1. Non-activation Suspension Tests

These tests were all negative.

2. Activation Suspension Tests

These tests were negative. The low dose with monkey lung showed an elevated response at the tryptophan locus. Because this response was not supported by other tests or by the adenine locus in the same test, the response was considered aberrant.

C. Conclusions

This compound was not genetically active under the test conditions employed in this evaluation.

Submitted by:

David Brusick

David Brusick, Ph.D.
Director
Department of Genetics



BIONETICS

APPENDIX

SUMMARY OF TESTS EVALUATING DMSO FOR GENETIC
ACTIVITY IN SALMONELLA AND SACCHAROMYCES



BIONETICS

COMPOUND DIMETHYSULFOXIDE

A. Suspension Tests

Test	<u>Activation</u>		<u>Salmonella Reversion Frequencies (x 10⁻⁸)</u>		<u>Saccharomyces D4 Conversion Frequencies (x 10⁻⁵)</u>	
	Species ^a	Organ ^b	TA-1535	TA-1538	Ade ⁺	Try ⁺
<u>Non-activation</u>						
Control (-C)	-	-	0.74	0.88	32.51	4.34
High Dose ^c	-	-	1.91	1.05	28.32	2.95
Low Dose ^d	-	-	0.53	1.37	40.73	0.49
<u>Activation</u>						
Control (+C)	-	-	1.80	0.36	38.27	2.47
Control (-C)	-	-	1.43	1.04	37.12	2.64
High Dose ^c	M	Li	0.34	1.07	47.77	2.75
	M	Lu	0.59	0.58	36.29	1.39
	M	T	0.62	0.30	34.35	1.94
Low Dose ^d	M	Li	-	0.87	34.02	1.18
	M	Lu	0.43	3.14	42.30	1.40
	M	T	0.11	0.39	45.95	2.32

Note: (-C) = solvent control and (+C) = test chemical control without homogenate

a M = mouse
Mo = monkey
R = rat

b Li = liver
Lu = lung
T = testes

c Bacteria = 3%
Yeast = 5%

d Bacteria = 1.5%
Yeast = 2.5%

COMPOUND DIMETHYSULFOXIDE

B. Plate Tests

Test	<u>Activation</u>		<u>Salmonella Responses</u>		
	Species ^a	Organ ^b	TA-1535	TA-1537	TA-1538
<u>Non-activation</u>					
Control (-C)	-	-	-	-	-
Test compound (3%)	-	-	-	-	-
<u>Activation</u>					
Control (+C)	-	-	-	-	-
Control (-C)	-	-	-	-	-
Test compound (3%)	M	Li	-	-	-
	M	Lu	-	-	-
	M	T	-	-	-
	R	Li	-	-	-
	R	Lu	-	-	-
	R	T	-	-	-
	Mo	Li	-	-	-
	Mo	Lu	-	-	-
	Mo	T	-	-	-

Note: (-C) = solvent control and (+C) = chemical control without homogenate

a M = mouse
Mo = monkey
R = rat

b Li = liver
Lu = lung
T = testes